REFRIGERATOR

MODELS:

MFT2976AEW00 (White)
MFT2976AEB00 (Black)
MFT2976AEM00 (Monochromatic Stainless)

© 2014 Maytag
Part No. W10526093 Rev. D

CABINET PARTS



CABINET PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W10568021	Tech Sheet
	W10558103	Use and Care Guide
	W10446593	Energy Guide
2	W10453401	Supply, Power
3	W10344432	Block, Pivot
4	W10505487	Gasket
5	W10581606	Board, Control
6	W10415341	Gasket, HV Box
7		Plug, Button
	A3076901	Black
8	W10141622	Brake, Roller
9	12992602	Screw
10		Hinge, Top
	W10248410	Left Hand
	W10248409	Right Hand
11	W10403208	Screw (White)
	W10403211	Screw (Black)
	W10403212	Screw (Grey)
12		Cover, Right Hinge
	W10248562	White
	W10407157	Black
	W10407158	Grey
13		Cover, Left Hinge
	W10471615	White
	W10471617	Black
	W10471618	Grey
14	W10308751	Screw (Black)
15		Hinge, Center (Right)
	W10248433	White
	W10248702	Black
	W10248703	Grey
16	W10336736	Cover, Roller
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18	W10394076	Valve, Water
19		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
20	12991302	Screw
21	12990701	Screw
22		Grille, Toe
	W10637668	White
	W10637669	Black
	W10637671	Grey
23	12992601	Screw
24		Hinge, Center (Left)
	W10248434	White
	W10248705	Black
	W10248706	Grey
25	W10141645	Screw
26	12990511	Screw
27	W10421948	Supply, Power LED
28	W10485658	Cover, Control Box
29	12466105	Switch, Light
30	W10544171	Cover, Back
31	M0108107	Clamp, Tube
32	W10558243	Tube, Water
33	W10491298	Tube, Drain
34	W10505294	Coupler, Door
35	W10212137	Retainer, Door
36		Cabinet (Not a Servicable Part)
37	W10271541	Connector, Union
38	549193	Clamp, Power Cord
39	W10141645	Screw
40	12990302	Screw
41	W10277839	Lid, HV

REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

Illus. No.	Part No.	Description
1		Liner (Not A Serviceable Part)
2	W10657942	Housing, Water System
3	W10482107	Tube, Fill
4	W10394084	Reservoir, Water (Also Order Wire Tie Part 8567668 Qty.5)
5	W10341329	Valve, Dual Water
6	W10238156	Housing, Water Filter
7	W10279854	Enclosure, Valve
8	W10488685	Cover, Water
9	2223877	Latch, Push
10	W10277949	Door, Filter Access
11	W10609378	Filter, Water
12	W10315189	Filter, Air
13	W10515793	Waterline, Valve to Hinge
14	W10554299	Heater, Fill Tube
15	12990518	Screw
16	W10598013	Cover, Icebox
17	W10492817	Assembly, Icebox (Foamed)
18	W10469927	Enclosure, Evaporator
19	W10537710	Pan, Drain
20	W10505516	Trim, Icebox
21	W10460280	Assembly, Blower
22		Evaporator Assembly - For more information on this service part, please contact 1-800-832-7174
23	W10637153	Assembly, LED Light Module
24	W10395278	Motor, Fan (Also Order Fan Support #W10389152)
25	W10553630	Assembly, Fascia
26	C3680310V	Switch, Light
27	W10434481	Bracket, Reservoir
28	W10280983	Insulation
29	W10389152	Support, Fan
30	W10635022	Adapter, Icebox
31	W10389154	Retainer, Damper
32	W10389149	Support, Damper
33	W10248595	Damper, Electronic Control
34	W10438957	Cover, Thermistor
35	W10501260	Cover, Evaporator
37	W10280988	Gasket, Rear Supply
38	W10320706	Gasket, Rear Return
40	W10392172	Gasket, Fan
41	W10518047	Assembly, Air Tower
		Following Parts Not Illustrated
	W10277799	Harness, Evaporator Wire (Includes Thermistors)
	W10570599	Harness, Dual Valve
	W10277801	Harness, Refrigerator Lights
	W10578603	Harness, Refrigerator Lights

FREEZER LINER PARTS



FREEZER LINER PARTS

Illus. No.	Part No.	Description
1		Liner (Not A Seviceable Part)
2	A3189392	Gasket, Foam
3	W10637153	Assembly, LED Light Module
4	W10513424	Cover, Evaporator
5	12990511	Screw
6	12956601	Clip, Fan Motor
7	C3680310V	Switch, Light
8	12990504	Screw
9	W10496613	Grille, Air (Freezer)
10	W10363507	Shroud, Evaporator Fan
11	12986101	Blade, Fan
12	12951101	Grommet, Fan Motor
13	W10514110	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)
14	W10503218	Funnel, Drain
15	M0500703	Seal
16	B8381501	Gasket, Drain
17	W10405166	Cover, Thermistor
18	W10531268	Gasket, Dual Evaporator
19	W10280385	Thermistor

REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Left
	W10417771	White
	W10417772	Black
	W10417773	Stainless
2		Door, Right
	W10340316	White
	W10341282	Black
	W10341284	Stainless
3	W10464016	Screw
4	W10549591	Assembly, Ice Door
5		Latch, Door
	W10355634	Left Hand
	W10372267	Right Hand
6		Mullion, Door
	W10654760	White
	W10654761	Black
	W10654762	Grey
7	12990204	Screw
8		Handle, Door
	W10439228	White
	W10439229	Black
	W10439227	Stainless
9	12990504	Screw
10		Bumper, Door
	W10407175	White
11	W10170766	Badge
12	W10460893	Screw
13	W10555427	Trivet, 2 Liter
14	W10519670	Bucket, Gallon
15	489214	Screw
16	W10347085	Gasket, Ice Door
17	W10245516	Clip, Tube
18	W10518658	Board, Receiver Circuit
19	W10258510	Cover, Receiver
20	3400065	Screw (Stainless)
21	W10258502	Cover, Emitter
22	W10258540	Slide, Icemaker Shut Off
23	W10518659	Board, Emitter Circuit
24	W10400825	Retainer, Ice Chute
25	W10347087	Gasket, Ice Chute
26	W10646855	Vent, Thermistor
27	W10258520	Door, Emitter
28	2198635	Spring, Door
29	2198634	Pin, Door
30		Gasket, Door
	W10249089	White
	W10407145	Black
	W10407146	Grey
31	W10515777	Tube, Water

FREEZER DOOR PARTS



FREEZER DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Freezer
	W10340319	White
	W10341277	Black
	W10341279	Stainless
2		Handle, Door
	W10439057	White
	W10439225	Black
	W10439226	Stainless
3	W10460893	Screw
4	W10503522	Shaft
5		Assembly, Bracket
	W10638293	Left Hand
	W10638294	Right Hand
6	W10594047	Bin, Lower
7	12990518	Screw
8	W10491768	Bin, Upper
9	W10248509	Clip, Shaft
10	W10507444	Divider, Lower
12		Stop, Pan
	W10485096	Left Hand
	W10485089	Right Hand
13	W10485654	Divider, Upper
14	W10469177	Support, Pan
15	489443	Screw (Stainless)
16		Gasket, Door
	W10249094	White
	W10248748	Black
	W10248749	Grey

UNIT PARTS


1
20
10
23
24
27
18
19
17
21
33
30
26
11
34
25
29
9
22
2
15
35
8
5
28
13
3
4
14
16
7
32
31
12
6
32

UNIT PARTS

Illus. No.	Part No.	Description
1	W10494227	Cord, Power
2	12825802	Blade, Fan
3	W10570074	Baseplate
4	12990511	Screw
5	W10547687	Extension, Drain
6	W10391081	Assembly, Valve Body
7	W10303521	Sleeve
8	W10238584	Tray, Evaporator
9	W10622701	Screw
10	12729128	Heater, Defrost
11	W10465778	Box, Inverter
12	W10248621	Clip, Condenser
13	12477102	Roller
14	12992101	Screw
15	10835903	Grommet
16	W10627646	Assembly, Condenser
17	W10391376	Bracket, Valve
18	W10342573	Tray, Drip
19	W10141625	Screw
20	W10608485	Evaporator
21	W10364560	Coil, 3 Way Valve
22	2188874	Motor, Condenser
23	10428101	Clip, Heater
24	W10491355	Gasket, Airdam
25	W10286069	Drier
26	W10168473	Compressor
27	W10142294	Screw
28	12477202	Axle, Roller
29	W10406719	Shroud
30	W10442270	Harness, Unit
31	W10278140	Cover, Bottom Unit
32	W10296661	Clip, Bottom Cover
33	W10626970	Assembly, Suction Tube
34	W10236396	Strap, Compressor
35	W10413009	Grommet, Air Return
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 7.25 oz. (R-134A)

SHELF PARTS


11
11
8
13
29
30
5
36
3
7
28
4
27
33
32
34
31
35
19
18
26
14
9
17
2
25
24
25
2
38
37
12
10
1
15
22
21
27
25
23

SHELF PARTS

Illus. No.	Part No.	Description
1	W10559660	Front, Pantry
2	W10530317	Plate, Slide Center
3	W10489978	Support, Pantry
4	W10248516	Ladder, Center
5	W10248799	Glass, Pantry
7	W10422682	Pan, Crisper
8	W10401836	Shelf, Tuck
9	W10524914	Front, Crisper
10	W10514690	Pan, Pantry
11	W10402687	Shelf, Fixed
12	W10467369	Divider, Pantry
13	W10372170	Ladder, Side
14	W10248578	Glass, Crisper
15	W10316419	Cover, Crisper
17	W10410352	Pan, Crisper
18		Plate, Side Pantry
	W10248834	Left Hand
	W10317523	Right Hand
19		Slide, Pantry
	W10248531	Left Hand
	W10248532	Right Hand
21		Plate, Crisper
	W10530318	Left Hand
	W10530306	Right Hand
22	W10530316	Plate, Side
23	W10488299	Front, Sideplate (Crisper)
24	W10530307	Track, Center
25	W10248819	Slide, Crisper
26	12990518	Screw
27	W10236512	Support, Front
28	W10423560	Screw
29	W10408747	Holder, Filter
30	W10346771	Filter, Produce Preserver
31	W10584148	Cover, Front (Includes LED Assembly)
32	W10525199	Cover, Top
33	W10565997	Assembly, User Interface
34	W10442183	Assembly, Pantry Wire (Includes Thermistor)
35	12990204	Screw
36	W10490266	Support, Pantry Cover
37		Front, Sideplate (Pantry)
	W10426775	Left Hand
	W10356979	Right Hand
38	W10530315	Support, Crisper

DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

Illus. No.	Part No.	Description
1		Housing, Dispenser (Not Serviced)
2		Assembly, User Interface
	W10549068	White
	W10549041	Black
	W10549067	Stainless
3		Wall, Dispenser False
	W10520867	White
	W10520868	Black
	W10520869	Grey
4		Assembly, Pad
	W10436679	White
	W10436677	Black
	W10436678	Stainless
5		Ring, Trim
	W10587907	White
	W10322864	Black
	W10423497	Stainless
6	W10577864	Assembly, Seperator
7	W10435760	Guide, Ice
8		Tray, Drip
	W10322872	White
	W10322873	Black
	W10410105	Grey
9	W10470750	LED Assembly

MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

Illus. No.	Part No.	Description
1	W10272364	Screw
2	W10347051	Plate, Ice Chute
3	2198628	Seal
4	W10347120	Clip, Retainer
5	W10347114	Shaft, Motor
6	W10215646	Motor, Dispenser
7	8281163	Screw (Stainless)
8	W10347093	Assembly, Ice Container

ICEMAKER PARTS



ICEMAKER PARTS

Illus. No.	Part No.	Description
1	W10498261	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White

MISCELLANEOUS

Illus. No.	Part No.	Description
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

Illus. No.	Part No.	Description
	1117510	Torx Key